



## Bean-e-doo Mastic Remover How-To Guide

### Step 1: Preparation

- Cover areas at risk of over-spray with plastic drop cloth
- Newly poured concrete must cure for 30 days before application
- For existing concrete:
  - Remove paint or previously applied sealer using Soy Gel Stripper
  - Remove oils, dirt, debris, Bean-e-doo Mastic Remover, using Scrub Brush and ProClean™ Degreaser
- Allow concrete to thoroughly dry before Application

### Step 2: Application

Coverage rate is approximately 200 square feet per gallon. Coverage rates may vary based on concrete texture, surface porosity, and application method.

NOTE: Bean-e-doo Mastic Remover is sensitive to temperature. Before applying, allow it to acclimate to climate of surface area location. Only apply when surface temperature is between 60°F (16°C) and 95°F (35°C).

Caution: May be harmful if swallowed or ingested. Contact with skin can cause mild irritation. Avoid contact with eyes.

- Use a straw broom, long-handled brush, or floor squeegee to spread Bean-e-doo evenly
- Allow product to sit until mastics soften
  - Asbestos/black mastics will soften in 2 hours
  - Vinyl or acrylic mastics will soften in 8 hours
- Once mastic has softened, remove it with a floor scraper
  - Some mastics are applied thicker than others and require additional coats of Bean-e-doo Mastic Remover
- Immediately rinse surface with water until surface is clear of residue
- After rinsing, apply water to various areas on concrete and scrub with a brush
  - If water turns cloudy, there is still Bean-e-doo Mastic Stripper on surface that must be cleaned
- Dry for at least 8 hours before applying a stain or sealer

### Pro Tips:

- Do not allow Bean-e-doo Mastic Remover to dry on surface
- Protect floor drains and sites where product would naturally flow on uneven surfaces with sand, Oil-Dri® sorbent material, or kitty litter
- A rotary floor scrubber or a buffer with a green pad used on a low rpm speed helps during cleanup steps

### Clean-Up:

- Clean tools with ProClean™ Degreaser and warm water



## Bean-e-doo Mastic Remover How-To Guide

### Tools & Supplies:

- ProClean™ Degreaser
- Plastic Drop Cloth
- Straw broom, Scrub Brush or floor squeegee
- Floor scraper
- Wet-Dry Vac or cotton mop and bucket

*Disclaimer: Direct Colors does not warranty or guarantee outcomes. Concrete variations or improper application may cause unintended results. Test product on an inconspicuous or small area and allow to fully cure to ensure compatibility and desired result.*