

EverStain™ How-To Guide

Step 1: Preparation

- Cover areas at risk of over-spray with plastic drop cloth
- Newly poured concrete must cure for 30 days before application
- For existing concrete:
 - o Remove paint or previously applied sealer using Soy Gel Stripper
 - o Remove carpet glue or other adhesives using Bean-e-doo Mastic Remover
 - o Remove oils, dirt, debris, Soy Gel Stripper, Bean-e-doo Mastic Remover, using Scrub Brush and ProClean Degreaser™
- Verify absorption by pouring a cup of water in various areas. If not absorbed within 5 minutes, etch the surface with Hard Troweled Floor Pre-Treatment
- Allow the concrete to thoroughly dry before Application

Step 2: Application

Coverage rate is approximately 200 square feet per gallon (two coats). Coverage rates may vary based on concrete texture, surface porosity, and application method.

NOTE: Only apply EverStain[™] when surface temperature is between 40 °F (4 °C) and 95 °F (35 °C) and wear Spiked Shoes to avoid leaving footprints before surface is neutralized.

Caution: Harmful if swallowed or ingested. Contact with skin can cause irritation. Avoid contact with eyes.

Spraying:

- Remove all filters from Pump-Up Sprayer before pouring EverStain™ into sprayer
- Wear Spiked Shoes before spraying EverStain™ or walking across surface until it's neutralized
- Begin spraying at a far corner to maintain a clear path to exit
- Spray EverStain™ on surface in circular motions with irregular overlaps
- To develop deeper color, apply additional coats (maximum of 2 coats)
- Allow 30 minutes between coats
 - o Apply additional coats following the same method
- Allow stain to react and develop color over 4-6 hours (richer colors may take more time)
- Once desired color has developed, neutralize stain using ProClean Neutralizer™
 - o Spray a saturating coat of ProClean Neutralizer™ on surface, allow to sit for 15 minutes
 - o Use Scrub Brush to break up all remaining EverStain™ residue
 - o Immediately rinse surface with water until surface is clear of residue (repeat steps as needed)
- Allow concrete to thoroughly dry for at least 8 hours before applying a sealer
- As surface dries color begins to look chalky or faded, this is normal. Color will "pop" once sealer is applied

Step 3: Seal & Protect Finish

- Apply 2 thin coats of sealer (AcquaSeal[™] Water-Based Acrylic Sealer or EasySeal[™] Solvent-Based Acrylic Sealer)
 - o For interior only: Also apply 2 thin coats of ProWax Polish™



EverStain™ How-To Guide

• For additional application instructions, see AcquaSeal™, EasySeal™, and ProWax Polish™ How-To Guides

Pro Tips:

- Darker acid stain colors will override lighter colors. If lighter colors are applied first, follow-up with darker colors. If darker colors are applied first, leave bare spots to fill-in with lighter colors
- EverStain™ reacts with minerals found in Portland Cement. Areas with more minerals will develop more color than areas with less minerals. EverStain™ will not stain rock or sand
- If new concrete is being poured it must have less than 10% Fly Ash for EverStain™ to work properly
- To avoid droplets dripping onto surface, before releasing sprayer trigger immediately place tip in a bucket

Clean-Up:

- Neutralize tools and supplies with ProClean Neutralizer™
- Then wash tools and supplies with ProClean Degreaser™ and warm water

Maintenance:

- For exterior: Protect finish every 2 years or as needed with either AcquaSeal™ Water-Based Acrylic Sealer or EasySeal™ Solvent-Based Acrylic Sealer
- For interior: Protect finish every 2 years with ProWax Polish™ or spot treat high-traffic areas as needed
- For additional application instructions, see AcquaSeal™, EasySeal™, and ProWax Polish™ How-To Guides

Tools & Supplies:

- Pump-Up Sprayer
- Plastic Drop Cloth
- Scrub Brush
- Spiked Shoes

Disclaimer: Direct Colors does not warranty or guarantee outcomes. Concrete variations or improper application may cause unintended results. Test product on an inconspicuous or small area and allow to fully cure to ensure compatibility and desired result.