



## ColorWave® Water-Based Concrete Stain How-To Guide

### Step 1: Preparation

- Cover areas at risk of over-spray with plastic drop cloth.
- Newly poured concrete must cure for 30 days before application.
- For existing concrete:
  - Remove paint or previously applied sealer using Soy Gel Stripper.
  - Remove carpet glue or other adhesives using Bean-E-Doo® Mastic Remover.
  - Remove any oils, dirt, debris, Soy Gel Stripper, or Bean-E-Doo® Mastic Remover using scrub brush and ProClean Degreaser™.
- Verify absorption by pouring a cup of water in various areas. If not absorbed within five minutes, etch the surface with CitrusEtch™, then neutralize surface with ProClean Neutralizer™ and rinse thoroughly.
- Allow the concrete to thoroughly dry before application.

### Step 2: Application

Coverage rate is approximately 200 square feet per gallon. Coverage rates may vary based on concrete texture, surface porosity, and application method.

**NOTE:** Only apply ColorWave® Water-Based Concrete Stain when surface temperature is between 40 °F (4 °C) and 95 °F (35 °C).

**Caution:** May be harmful if swallowed or ingested. Contact with skin can cause mild irritation. Avoid contact with eyes.

#### Spraying:

- Remove all filters from pump-up sprayer.
- Shake ColorWave® well before pouring into sprayer.
- Begin spraying at a far corner to maintain a clear path to exit.
- Spray ColorWave® on surface in slightly circular motions with irregular overlaps.
  - Shake sprayer tank from side to side often to prevent color from settling.
  - Spray thin coats to avoid puddling.
- To develop deeper color, apply additional coats using the same method (maximum of four thin coats).
  - Allow eight hours between coats.
  - Dry for at least eight hours before applying a sealer.

### Step 3: Seal & Protect Finish

- Apply two thin coats of sealer with AcquaSeal™ or EasySeal™.
  - For interior only: Also apply two thin coats of ProWax Polish™.
- For additional application instructions, see AcquaSeal™, EasySeal™, and ProWax Polish™ How-To Guides.

#### Pro Tips:

- To avoid droplets dripping onto surface: before releasing sprayer trigger, immediately place tip in a bucket.
- Multiple colors may be creatively layered or blended.

Customer Service | Email: [cs@directcolors.com](mailto:cs@directcolors.com) | Phone: (877) 255-2656  
[www.directcolors.com](http://www.directcolors.com)

© Direct Colors LLC. All Rights Reserved.



## ColorWave® Water-Based Concrete Stain How-To Guide

### Cleanup:

- Clean tools and supplies with ProClean Degreaser™ and warm water.

### Maintenance:

- For exterior: Protect finish every two years as needed with AcquaSeal™ or EasySeal™.
- For interior: Protect finish every two years with ProWax Polish™ or spot treat high-traffic areas as needed.
- For additional application instructions, see AcquaSeal™, EasySeal™, and ProWax Polish™ How-To Guides.

### Tools & Supplies:

- Pump-up sprayer
- Plastic drop cloth
- Scrub brush
- Spiked shoes (if using CitrusEtch™)

*Disclaimer: Direct Colors does not warranty or guarantee results (outcomes). Concrete variations or improper application may cause unintended results. Test product on an inconspicuous or small area and allow to fully cure to ensure compatibility and desired result.*